



For unlisted items, call us at **954-340-0500**
Last updated 06/1/2010

	Assembly Description	Assembly Number	Spare Part Number	Description
Soft Goods	Sentry 1200	43-SM42	40A42-S	Shell/ MR Assy/ Small MR
Soft Goods	Sentry 1200	43-SM42	40A42-S-HG	Shell/Hosp Grade/Small MR assy
Soft Goods	Sentry 1200	43-SM42	40A34SZ	Coverlet Assy/Zipper/S1200/PC
Soft Goods	Sentry 1200	43-SM42	40A42-AC	Air cell/Small/ Sentry & PC
Soft Goods	Sentry 1200	43-SM42	DP-P10410	CPR Pull/PlsticMold/Red/Urethn
Soft Goods	Sentry 1200	43-SM42	52A822	CPR/ThinBlock/HoseAsy/1 zone M
Soft Goods	Sentry 1200	43-SM42	40A42-ML	Mattress Loop Asy/ Small
Soft Goods	Sentry Intergrated Bolster	42-SM42	42A42-S-IB	Shell/ Integrated bolster MR
Soft Goods	Sentry Intergrated Bolster	42-SM42	42A42-S-IB-LP	Shell/ Integ Bolster/ LowProfil
Soft Goods	Sentry Intergrated Bolster	42-SM42	42A42-AC-FBL	Air Cell/Foot Bolster/Left(IB)
Soft Goods	Sentry Intergrated Bolster	42-SM42	42A42-AC-FBR	Air Cell/Foot Bolster/Right/IB
Soft Goods	Sentry Intergrated Bolster	42-SM42	42A42-AC-HBL	Air Cell/Head Bolster/Left(IB)
Soft Goods	Sentry Intergrated Bolster	42-SM42	42A42-AC-HBR	Air Cell/Head Bolster/Right/IB
Soft Goods	Sentry Intergrated Bolster	42-SM42	40A42-AC-IB	AirCell/Sentry/IntegratBolstr
Soft Goods	Sentry Intergrated Bolster	42-SM42	42A42-ML-IB-LP	MattLoop/IntgrBolster/LowProfil
Soft Goods	Sentry Intergrated Bolster	42-SM42	42A42-ML-IB	MattressLoop Asy/Intgr Bolster
Controller	Sentry 1200	04-SM1200	EK-SF	Socket/PwrCord/AllContr
Controller	Sentry 1200	04-SM1200	00A1203	Back Cover Assy/ PC & 1200
Controller	Sentry 1200	04-SM1200	DP-P10408	AirSocket PlasticCase/Panel Mt
Controller	Sentry 1200	04-SM1200	IL-P10425	Inlay/PlsCs/DisplayWindow/1200